



- L** left speaker
- C** center speaker
- R** right speaker
-  Atmos ceiling mounted speaker
- SUB** sub-woffer

- LS** left side speaker
- RS** right side speaker

-  Atmos ceiling mounted speaker
- RR** right rear speaker
- LR** left rear speaker